

Reusable On-the-Go™ Bottle Warmer

To Use: Wrap the warmer pouch around a bottle/jar of food. Insert bottle/jar with warmer into the insulated bag. Firmly bend/snap the metal disc. The solution will turn white, heat up and harden. If the pouch does not heat up repeat the process. For best results, close top of bag to prevent heat loss. Warmer will reach maximum temperature in approximately 30 minutes.

To Reactivate: Fully immerse warmer pouch in pan of boiling water and boil until solution becomes completely clear (approximately 10-15 minutes). Do not allow pan to boil dry. Allow water to cool before removing the pouch. Ensure pouch contents have liquefied (no crystals remain); if not, repeat process. Alternatively, place warmer pouch in a non-microwavable steam steriliser for one cycle. Remove carefully as contents are hot. Allow to cool completely before using.

Warning: Do not puncture pouch. Do not microwave. Keep out of reach of children.



PRINCE LIONHEART®
Because your baby deserves the very best!™

USA: Prince Lionheart, Inc., 2421 S. Westgate Rd., Santa Maria, CA 93455 USA Phone: (805) 922-2250

EUROPE: Prince Lionheart UK Ltd., 4 Sovereign Park, Coronation Road, London NW10 7QP, England Phone: +44 (0) 870 766 5197

www.princelionheart.com Email: customerservice@princelionheart.com

WAIT!

Before use, check to see if
the Warmer is ready.

READY

The solution in the Warmer is clear and soft.

NOT READY

The solution in the warmer is white and
hardened.

TO REACTIVATE

Please boil/steam according to instructions.